Thank you for purchasing the matching enclosure for your VEC-1680K *Vacuum Tube Audio Preamplifier Kit.* The matching enclosure is an all metal cover, with mounting screws, to protect your tube.

To install your VEC-1680KC matching enclosure follow these instructions:

- 1. Remove all debris and oil from the enclosure. You can do this with a piece of cloth and alcohol.
- 2. Find the four (4) self-tapping (#4 x"/4", type B) screws.
- 3. Align the enclosure with the four pilot holes.
- 4. With a philips head type screw drive, secure the enclosure using the selftapping screws. The screws should be snug-do not over tighten.

